Calculate NDVI & Extract Spectra with Masks

Background:

The Normalized Difference Vegetation Index (NDVI) is a standard band-ratio calculation frequently used to analyze ecological remote sensing data. NDVI indicates whether the remotely-sensed target contains live green vegetation. When sunlight strikes objects, certain wavelengths of the electromagnetic spectrum are absorbed and other wavelengths are reflected. The pigment chlorophyll in plant leaves strongly absorbs visible light (with wavelengths in the range of 400-700 nm) for use in photosynthesis. The cell structure of the leaves, however, strongly reflects near-infrared light (wavelengths ranging from 700 - 1100 nm). Plants reflect up to 60% more light in the near infrared portion of the spectrum than they do in the green portion of the spectrum. By calculating the ratio of Near Infrared (NIR) to Visible (VIS) bands in hyperspectral data, we can obtain a metric of vegetation density and health.

The formula for NDVI is:




Figure: (Wu et al. 2014)

Start by setting plot preferences and loading the neon_aop_refl_hdf5_functions module:


```
In [1]: import numpy as np
    import matplotlib.pyplot as plt
    %matplotlib inline
    import warnings
    warnings.filterwarnings('ignore') #don't display warnings
```

```
In [2]:
        # %load ../neon aop hyperspectral.py
        Created on Wed Jun 20 10:34:49 2018
        @author: bhass
        import matplotlib.pyplot as plt
        import numpy as np
        import h5py, os, copy
        def aop_h5refl2array(refl_filename):
             """aop_h5refl2array reads in a NEON AOP reflectance hdf5 file and returns
                   1. reflectance array (with the no data value and reflectance scale factor applied)
                   2. dictionary of metadata including spatial information, and wavelengths of the bands
            Parameters
                refl_filename -- full or relative path and name of reflectance hdf5 file
            Returns
            reflArray:
                array of reflectance values
                dictionary containing the following metadata:
                    bad_band_window1 (tuple)
                    bad_band_window2 (tuple)
                    bands: # of bands (float)
                    data ignore value: value corresponding to no data (float)
                    epsg: coordinate system code (float)
                    map info: coordinate system, datum & ellipsoid, pixel dimensions, and origin coordinates (string)
                    reflectance scale factor: factor by which reflectance is scaled (float)
                    wavelength: wavelength values (float)
                    wavelength unit: 'm' (string)
            NOTE: This function applies to the NEON hdf5 format implemented in 2016, and should be used for
            data acquired 2016 and after. Data in earlier NEON hdf5 format (collected prior to 2016) is
            expected to be re-processed after the 2018 flight season.
            Example Execution:
            sercRef1, sercRef1 metadata = h5ref12array('NEON D02 SERC DP3 368000 4306000 reflectance.h5') """
            import h5py
            #Read in reflectance hdf5 file
            hdf5_file = h5py.File(refl_filename, 'r')
            #Get the site name
            file_attrs_string = str(list(hdf5_file.items()))
            file_attrs_string_split = file_attrs_string.split("'")
            sitename = file_attrs_string_split[1]
            #Extract the reflectance & wavelength datasets
            refl = hdf5 file[sitename]['Reflectance']
            reflData = refl['Reflectance Data']
            reflRaw = refl['Reflectance Data'].value
            #Create dictionary containing relevant metadata information
            metadata = {}
            metadata['map info'] = refl['Metadata']['Coordinate_System']['Map_Info'].value
            metadata['wavelength'] = refl['Metadata']['Spectral_Data']['Wavelength'].value
            #Extract no data value & scale factor
            metadata['data ignore value'] = float(reflData.attrs['Data_Ignore_Value'])
            metadata['reflectance scale factor'] = float(reflData.attrs['Scale_Factor'])
            #metadata['interleave'] = reflData.attrs['Interleave']
            #Apply no data value
            reflClean = reflRaw.astype(float)
            arr size = reflClean.shape
            if metadata['data ignore value'] in reflRaw:
                print('% No Data: ',np.round(np.count_nonzero(reflClean==metadata['data ignore value'])*100/(arr_size[
                nodata_ind = np.where(reflClean==metadata['data ignore value'])
```

```
reflClean[nodata_ind]=np.nan
   #Apply scale factor
   reflArray = reflClean/metadata['reflectance scale factor']
   #Extract spatial extent from attributes
   metadata['spatial extent'] = reflData.attrs['Spatial_Extent_meters']
   #Extract bad band windows
   metadata['bad band window1'] = (refl.attrs['Band_Window_1_Nanometers'])
   metadata['bad band window2'] = (refl.attrs['Band_Window_2_Nanometers'])
   #Extract projection information
   #metadata['projection'] = refl['Metadata']['Coordinate System']['Proj4'].value
   metadata['epsg'] = int(refl['Metadata']['Coordinate_System']['EPSG Code'].value)
   #Extract map information: spatial extent & resolution (pixel size)
   mapInfo = refl['Metadata']['Coordinate System']['Map Info'].value
   hdf5_file.close
   return reflArray, metadata
def plot_aop_ref1(band_array,ref1_extent,colorlimit=(0,1),ax=plt.gca(),title='',cbar ='on',cmap_title='',color
    '''plot_refl_data reads in and plots a single band or 3 stacked bands of a reflectance array
   Parameters
       band_array: array of reflectance values, created from aop_h5refl2array
       refl extent: extent of reflectance data to be plotted (xMin, xMax, yMin, yMax)
                    use metadata['spatial extent'] from aop_h5refl2array function
        colorlimit: optional, range of values to plot (min, max).
                    - helpful to look at the histogram of reflectance values before plotting to determine col
       ax: optional, default = current axis
       title: optional; plot title (string)
       cmap_title: optional; colorbar title
       colormap: optional (string, see https://matplotlib.org/examples/color/colormaps_reference.html) for li
   Returns
       plots flightline array of single band of reflectance data
   Examples:
   plot_aop_refl(sercb56,
             sercMetadata['spatial extent'],
             colorlimit=(0,0.3),
             title='SERC Band 56 Reflectance',
             cmap_title='Reflectance',
              colormap='Greys_r') '
   import matplotlib.pyplot as plt
   plot = plt.imshow(band_array,extent=refl_extent,clim=colorlimit);
       cbar = plt.colorbar(plot,aspect=40); plt.set_cmap(colormap);
       cbar.set_label(cmap_title,rotation=90,labelpad=20)
   plt.title(title); ax = plt.gca();
   ax.ticklabel_format(useOffset=False, style='plain'); #do not use scientific notation for ticklabels
   rotatexlabels = plt.setp(ax.get_xticklabels(),rotation=90); #rotate x tick Labels 90 degrees
def stack_rgb(reflArray,bands):
   red = reflArray[:,:,bands[0]-1]
   green = reflArray[:,:,bands[1]-1]
   blue = reflArray[:,:,bands[2]-1]
   stackedRGB = np.stack((red,green,blue),axis=2)
   return stackedRGB
def plot aop rgb(rgbArray,ext,ls pct=5,plot title=''):
```

```
from skimage import exposure

pLow, pHigh = np.percentile(rgbArray[~np.isnan(rgbArray)], (ls_pct,100-ls_pct))
img_rescale = exposure.rescale_intensity(rgbArray, in_range=(pLow,pHigh))
plt.imshow(img_rescale,extent=ext)
plt.title(plot_title + '\n Linear ' + str(ls_pct) + '% Contrast Stretch');
ax = plt.gca(); ax.ticklabel_format(useOffset=False, style='plain') #do not use scientific notation #
rotatexlabels = plt.setp(ax.get_xticklabels(),rotation=90) #rotate x tick Labels 90 degree
```



Read in SERC Reflectance Tile

```
In [3]: sercRefl, sercRefl_md = aop_h5refl2array('../data/NEON_D02_SERC_DP3_368000_4306000_reflectance.h5')
```

Extract NIR and VIS bands

Now that we have uploaded all the required functions, we can calculate NDVI and plot it. Below we print the center wavelengths that these bands correspond to:

```
In [4]: print('band 58 center wavelength (nm): ',sercRefl_md['wavelength'][57])
    print('band 90 center wavelength (nm): ', sercRefl_md['wavelength'][89])

band 58 center wavelength (nm): 668.985
    band 90 center wavelength (nm): 829.238
```


Calculate NDVI & Plot

Here we see that band 58 represents red visible light, while band 90 is in the NIR portion of the spectrum. Let's extract these two bands from the reflectance array and calculate the ratio using the numpy.divide which divides arrays element-wise.

```
In [5]: vis = sercRefl[:,:,57]
    nir = sercRefl[:,:,89]

    ndvi = np.divide((nir-vis),(nir+vis))
```


We can use the function plot_aop_refl to plot this, and choose the seismic color pallette to highlight the difference between positive and negative NDVI values. Since this is a normalized index, the values should range from -1 to +1.



Extract Spectra Using Masks

In the second part of this tutorial, we will learn how to extract the average spectra of pixels whose NDVI exceeds a specified threshold value. There are several ways to do this using <code>numpy</code>, including the mask functions <code>numpy.ma</code>, as well as <code>numpy.where</code> and finally using <code>boolean</code> indexing.

To start, lets copy the NDVI calculated above and use booleans to create an array only containing NDVI > 0.6.



Calculate the mean spectra for reflectance values thresholed by NDVI

Below we will demonstrate how to calculate statistics on arrays where you have applied a mask <code>numpy.ma</code> . In this example, the function calculates the mean spectra for values that remain after masking out values by a specified threshold.

```
In [9]: import numpy.ma as ma
  def calculate_mean_masked_spectra(reflArray,ndvi,ndvi_threshold,ineq='>'):
    mean_masked_refl = np.zeros(reflArray.shape[2])
    for i in np.arange(reflArray.shape[2]):
        refl_band = reflArray[:,:,i]

        if ineq == '>':
            ndvi_mask = ma.masked_where((ndvi<=ndvi_threshold) | (np.isnan(ndvi)),ndvi)
        elif ineq == '<':
            ndvi_mask = ma.masked_where((ndvi>=ndvi_threshold) | (np.isnan(ndvi)),ndvi)
        else:
            print('ERROR: Invalid inequality. Enter < or >')

        masked_refl = ma.MaskedArray(refl_band,mask=ndvi_mask.mask)
        mean_masked_refl[i] = ma.mean(masked_refl)

    return mean_masked_refl
```

We can test out this function for various NDVI thresholds. We'll test two together, and you can try out different values on your own. Let's look at the average spectra for healthy vegetation (NDVI > 0.6), and for a lower threshold (NDVI < 0.3).

```
In [10]: sercSpectra_ndvi_gtpt6 = calculate_mean_masked_spectra(sercRefl,ndvi,0.6)
sercSpectra_ndvi_ltpt3 = calculate_mean_masked_spectra(sercRefl,ndvi,0.3,ineq='<')</pre>
```

Finally, we can use pandas to plot the mean spectra. First set up the pandas dataframe.


```
In [11]: import pandas

#Remove water vapor bad band windows & Last 10 bands
w = copy.copy(sercRefl_md['wavelength'])
w[((w >= 1340) & (w <= 1445)) | ((w >= 1790) & (w <= 1955))]=np.nan
w[-10:]=np.nan;

nan_ind = np.argwhere(np.isnan(w))

sercSpectra_ndvi_gtpt6[nan_ind] = np.nan
sercSpectra_ndvi_ltpt3[nan_ind] = np.nan
#Create dataframe with masked NDVI mean spectra
sercSpectra_ndvi_df = pandas.DataFrame()
sercSpectra_ndvi_df['wavelength'] = w
sercSpectra_ndvi_df['mean_refl_ndvi_gtpt6'] = sercSpectra_ndvi_gtpt6
sercSpectra_ndvi_df['mean_refl_ndvi_gtpt6'] = sercSpectra_ndvi_ltpt3</pre>
```

Plot the masked NDVI dataframe to display the mean spectra for NDVI values that exceed 0.6 and that are less than 0.3:



References

Wu C-D, McNeely E, Cedeño-Laurent JG, Pan W-C, Adamkiewicz G, Dominici F, et al. (2014) Linking Student Performance in Massachusetts Elementary Schools with the "Greenness" of School Surroundings Using Remote Sensing. PLoS ONE 9(10): e108548. doi:10.1371/journal.pone.0108548

https://www.researchgate.net/figure/266947355_fig1_Figure-1-Green-vegetation-left-absorbs-visible-light-and-reflects-near-infrared-light (https://www.researchgate.net/figure/266947355_fig1_Figure-1-Green-vegetation-left-absorbs-visible-light-and-reflects-near-infrared-light)